



- 101.Cast Control Knob
- 102.Cast Control Rubber Washer
- 103.Cast Control Brass Washer
- 104.Retaining Clip
- 105.O-Ring
- 106.Ball Bearing
- 107.Screw
- 108.Bait Clicker Button
- 109.Bait Clicker Button Washer
- 110. Left Side Plate
- 111.Location Pillar
- 112.Pawl Washer
- 113."E"-Retainer
- 114.Pawl
- 115.Pawl Spring
- 116.Pawl Tension Spring
- 117.Level Wind Gear
- 118."E"-Retainer
- 201.Worm Shaft Cover
- 203.Worm Shaft
- 204.Line Guard
- 205.Lind Guide
- 206.Line Guide Pawl
- 207.Line Guide Pawl Knob
- 208.Main Body Assembly
- 209.Ball Bearing
- 210.Bushing
- 211.Level Wind Pinion Gear
- 212.Spool Assembly
- 213.Centrifugal Brake Shoe
- 301.Right Gear Plate
- 302.Thumb Button
- 303.Latch Spring
- 304.Roke
- 305.Roke Spring
- 306.Pinion Gear
- 307.Right Side Plate
- 308.Screw
- 309.Ball Bearing
- 310.O-Ring
- 311.Retaining Clip
- 312.Cast Control Brass Washer
- 313.Cast Control Rubber Washer
- 314.Cast Control Knob
- 315.Crank Shaft
- 316.Clutch Disc
- 317.Drag Friction Disc
- 318.Main Gear
- 319.Drag Friction Disc
- 320.Cup Washer
- 321.Ear Washer
- 322.Drag Friction Disc
- 323.Cup Washer
- 324.Drag Spring Washer Bushing
- 325.Anti-Reverse Ball Bearing
- 401.Star Drag Handle
- 402.Handle Spring Washer
- 403.Handle
- 404.Handle Nut
- 405.Latch Keeper
- 406.Screw